




ASSEMBLY INSTRUCTIONS

Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratcheds. Refer steps provided as assembling guide.


CAUTIONS :

- 1.Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
- 2.To prevent thread damage.Ensure that nuts or nut bolts are not over-tighten.
- 3.Hardware are to be kept out of reach from children.






(A)



Bolt M8x60
X
02PCS

(B)



Bolt M6x50
X
04PCS

(C)




Washer
X
04PCS

(D)




Nuts M8x13 D15
X
02PCS

(E)




Allen key M4
X
02PCS

1




2




DO NOT TIGHTEN
BOLT AND NUTS COMPLETELY


3



4



DO NOT TIGHTEN
BOLT COMPLETELY



BE SURE TO CHECK ALL BOLTS ARE SECURELY TIGHTENED PRIOR TO USE.